

# *Super II*<sup>™</sup>

## User Manual

**Setra Systems, Inc**  
Weighing Systems Division  
159 Swanson Road  
Boxborough, MA 01719

SS2067 Rev E 0704

## Table of Contents

### Introduction

Introduction .....	3
Overview of the Super II Scale .....	6
Installing Your Scale .....	7
Understanding Your Scale .....	10
Keypad: Soft Keys .....	10
Keypad: Alphanumeric Keys .....	11
Keypad: Hard Keys .....	11
LEDs .....	12
Display Symbols .....	12
Back of the Controller .....	12

### User Functions

Basic Weighing .....	15
Weighing/Counting with a Container .....	15
Basic Counting Using the Default Soft Keys .....	16
Entering Numeric Values for ID, APW, COUNT, or TARE .....	17
Entering Alphanumeric Information into the ID Registers Using the Scale Keypad .....	18
Counting with Accuracy Enhancement .....	19
Reverse Counting or Kitting .....	20
Operating Your Scale Using a QWERTY Keyboard .....	21
Adjusting the Backlighting Option .....	23
Soft Key: SAVE .....	24
Soft Key: ACCUM .....	26
Soft Key: DISPLAY .....	27
Soft Key: DATABASE .....	28
Soft Key: SET PTS .....	30
Soft Key: ALARMS .....	31

Soft Key:UNITS .....	33
Soft Key:COUNTER.....	34
Appendix A: Glossary of Terms .....	35
Appendix B: Limited Two Year Scale Warranty .....	36
FCC Warning .....	37
Index .....	38

## Introduction



# Introduction

Thank you for purchasing a Setra Super II™ scale. Its ease of operation and durable construction should provide years of reliable service. While your scale is easy to operate, it is advisable to read this guide before use in order to help you perform weighing, counting, and related operations quickly and accurately.


The Super II scale comes with two separate manuals labeled “User Manual” and the “Supervisor and Technical Manual”. The “User Manual” is all that is necessary to be able to operate the scale in its default state. It explains all basic weighing and counting operations as well as how to print and use some of the more advanced features such as the database and the setpoints. The Supervisor and Technical Setups in the “Supervisor and Technical Manual” are for programming various features in your scale such as print formats, sample sizes and database usage as well as performance characteristics of your scale – calibration, resolution, and display update rate.

Due to the large amount of customization that can be programmed into your scale, it may not operate exactly the same way as in its default state. One advanced programming option is to have your scale follow a “Macro” which is a pre-programmed number of steps. Your scale can always be returned to its default state within Supervisor, Bases, and Technical Setup Menus (see “Supervisor and Technical Manual”).

Typographical conventions used in both manuals include the following:

1. **Bold** characters indicate keys on the scale keypad whether they are prompts listed above the soft keys or hard keys or any of the alphanumeric characters.
2. “Quotation marks” enclose messages that will appear on the scale’s display.
3. *nnn* indicates that a number will appear in the display message.

# Overview of the Super II Scale





# Installing Your Scale

## Setup

1. Locating your scale.  
The rugged design of your Super II scale ensures that it will be able to operate well in the typical factory or office environment. Nonetheless, you should always treat your scale as you would any other piece of precision equipment, locating it on a clean dry surface, protected from draft and vibration. CE certification only applies to use of the scale in an Indoor Environment.
2. Leveling your scale.  
Your scale has four adjustable feet with locking mechanisms. The bubble level is located in the center underneath the weighing pan. Once your scale is level, the feet should be locked into place by turning the star lock nut counter-clockwise until it is pressing firmly against the base casting.

## LEVELING THE SCALE






3. Connecting the controller.

Attach the coiled cord coming out of the Super II weighing base to the port marked BASE on the underside of the controller. If you would like to mount the controller to the base, refer to the diagram below.

1. Line up the controller with the three spring loaded screw washers on the base.
2. Press the controller onto the base in order to engage the screw heads and slide the controller to the left.
3. Press down on the controller to secure it into place.

To remove the controller, reverse the procedure listed above.

1. Lift up on the controller until it reaches its upper limit.
2. Move it down slightly as you slide it to the right.
3. Once in its farthest right position, the controller can be wiggled off.



4. Powering the scale.

The Super II scale comes standard with a 16V AC adapter designed to both power the scale and recharge the optional internal battery. It is recommended to first plug the AC adapter into an electrical outlet before connecting to the back of the scale. Once you have plugged your scale into a live outlet, it is automatically on. If the scale is equipped with the internal battery option, the on-off switch on the rear panel must be in the 'on' position to power-up the scale. The scale draws very little current from an outlet and may be left connected. This keeps your scale ready to use with no warm-up time.

5. Display test.

When your scale is first powered on, it displays the programmed time and date along with a greeting message that may be either Setra Systems' address and telephone number or that of the dealer who sold you the scale. There is also a count down procedure that lasts around thirty seconds during which time the controller pulls information from the base before settling on 0.000 weight. For best accuracy, allow the scale to warm up for 5 minutes or longer if changing environmental surroundings.

6. Experimenting with your scale.

Reference to this "User's Guide" along with the "Supervisor and Technical Setups" manual is the best way to learn about your scale and take full advantage of all its features. However, the Super II functionality and menu system is designed to be fully "prompt" driven. Experimenting with either the default keys or entering the menu by pressing the **menu** hard key will not alter your scale as long as you do not change the settings in either the Technical, Bases, or Supervisor setups. All menu selections end with an **EXIT** soft key that will bring you back to the main menu. There is also a **reset** hard key that clears all scale registers and brings you back to 0.000 weight.

# Understanding Your Scale

## Keypad: Soft Keys

The Super II keypad is divided into three groups of keys. The first set of keys underneath the display are referred to as “soft keys”. Their function changes depending on where you are in the counting procedure or which level you enter in the menu.

The default soft keys are listed below and have the following functions:

<b>ZERO</b>	Assigns the pan and whatever is currently being weighed a value of zero. While the scale is determining a stable weight reading, the display will indicate “Zero Base Process Activated”. A zeroing operation underway can be cancelled with a second pass of the <b>ZERO</b> key. Note: If a Tare value is stored in memory, it will be cleared.
<b>SAMPLE</b>	Determines a stable reference point and displays the preprogrammed sample sizes (10, 25, 50, 100 pieces). A <b>SAMPLE</b> size selection menu can be displayed if activated in the Supervisor setups (see <b>SAMPLE</b> soft key in the “Supervisor and Technical Setups Manual”).
<b>COUNT</b>	Instructs the scale to begin or resume counting.
<b>PRINT</b>	Instructs the scale to print preprogrammed fields or label format. If multiple label formats are active, a print menu is displayed in order to make a numeric print register selection.
<b>CLEAR</b>	Used to switch from Count (pieces) to Weight.
<b>LRG SPL</b>	Used to go to the next programmed sample size. For example, to go from “ADD 10 PIECES” to “ADD 25 PIECES”.
<b>UPDTAPW</b>	Used to recalculate the APW based on a larger sample size. The additional sample weight cannot exceed 100% of the previous sample to avoid the compounding of errors (see Counting with Accuracy Enhancements in this User Manual).
<b>EXIT</b>	Returns the display to either Weight or Count(pieces) depending on which was last active before the menu prompt.

## Keypad: Alphanumeric Keys

The second set of keys are the alphanumeric keys. These keys are used to enter numbers or values into the scale as well as alphanumeric information into the various ID registers. The default key functions are represented by the numbers on the bottom. To access the alpha characters or punctuation above the numbers, the **abc** hard key must be pressed. "ABC" will appear in the lower left side of the display indicating that you are now in the alpha entry mode. The ← left arrow is a backspace and the → right arrow is used either as a space or to move on to the next alpha character. Alphanumeric data entry into the Super II follows the cellular telephone standard (see Entering Alphanumeric ID's in this User Manual for more information).



## Keypad: Hard Keys

The last set of keys are referred to as the hard keys. There are five hard keys that have the following functions:

- tare** Instructs the scale to accept a numerical tare weight entry. If a container is placed on the pan, pressing **tare** assigns its weight as the "tare" (i.e. container weight), saves it to memory and displays it on the top line of the display. The weight or count displayed will then read net value (i.e. content weight or count).
- menu** Instructs the scale to enter the menu system. The soft keys will change to new functions. The first two levels of the menu system are user functions followed by a branch into either the Technical or Supervisor menus (see fold out for the Main Menu Tree of the "Supervisor and Technical Setups" manual).
- remote** Instructs the scale to switch to a secondary base (either strain gauge or Setra base) attached to the primary base connected to the controller. If multiple bases are attached or daisy chained, a menu will appear to allow base selection by numeric entry.
- abc** Instructs the scale to go into alpha entry mode. "ABC" will appear on the bottom left of the display and pressing an alphanumeric key will scroll through the alpha selection (see entering Alpha/Numeric ID's for more information).
- reset** Sets all counting and weighing registers to zero. Clears all volatile ID fields and assigns the pan (and anything on the pan) a value of 0.00 weight.

## LEDs

There are two LEDs on the keypad that are only active when the battery option is installed and in use.

low battery                “red”                Indicates that the battery needs to be charged.

charging                “green”                Indicates that the battery is being charged.

## Display Symbols

OK                Reading shown is stable.

ABC                Alphanumeric keypad is in the letter entry mode.

-----                The reading is outside the calibration range.

OL                The ----- is indicating an overload situation.

UL                The ----- reading is indicating an underload situation.

GROSS                The weight displayed is the gross weight on the pan including any tare weight.

## Back of the Controller

There are five ports labelled on the bottom of the controller. Their functions are as follows:

**BASE**                Port for connection to Setra base.

**KEYBOARD**                Port for connection to optional computer PS2® style QWERTY keyboard(not available from Setra). For CE compliance, Setra has certified the use of Behavior Tech Computer Corporation's Model BTC 5210 keyboard. Other manufacturer's keyboards may or may not affect the limitations set forth in CE certification. Setra cannot be responsible for other manufacturer's specifications.

**BI**                Bi-directional RS232 communications port for connection to a computer. Default port settings are 9600 baud, 8 data bits, no parity, 1 start, and 1 stop bit, hardware handshaking on (RTS/RTC).

**OUT**                RS232 output port for connection to a serial printer. Default port settings are 2400 baud, 8 data bits, no parity, 1 start, and 1 stop bit for the DYMOSetra Labelwriter 250 printer, no hardware handshaking.

**IN**                RS232 input port for connection to a bar code scanning device. +5V is supplied on pin 6. Default port settings are 2400 baud, 8 data bits, no parity, 1 start, and 1 stop bit for Setra Linear Imager Gun (403678) or Smart Wand (403676), no hardware handshaking.

®PS2 is a registered trademark of International Business Machines

**User Functions**



### Basic Weighing

To weigh an object on your scale, use the following procedure:

1. Press the **ZERO** key and wait for the display to show 0.00 weight with the "OK" stability indicator on.
2. Place the object(s) to be weighed on the pan.
3. Wait for the "OK" symbol, then read the weight from the display.

### Weighing/Counting with a Container

To weigh or count objects WITHOUT including the weight of the container, use the **tare** or **ZERO** keys. If you wish to retain the container weight for later reference or to print or display the gross weight, the **tare** key should be used. The tare weight of the container(s) will be displayed on the top line of the display until the **ZERO** or **reset** key is pressed. If you do not need to retain the container weight, the **ZERO** key should be used to eliminate the weight of the container(s).

If the tare weight of the container is known, a full container may be placed on the pan and the tare weight entered through the numeric keypad.

To tare or zero out the weight of the container, and then weigh or count the contents, use the following procedure:


1. Press the **ZERO** key. Place the container on the pan.
2. Press the **tare** or **ZERO** key. (If the container is not empty and tare weight is known, enter the value using the numeric keypad and then press the **tare** key).
3. Perform your weighing or counting application.




## Basic Counting Using the Default Soft Keys

Most counting applications can be successfully accomplished by using the 5 default soft keys at the bottom of the display. To count a number of like pieces on the scale, use the following procedure:


1. Place an empty container on the scale. Press the **ZERO** key.




2. Press the **SAMPLE** key. Each time the key is pressed the requested sample size will sequence to the next sample size in the sample size menu. (i.e. ADD 10, 25, 50, 100 PIECES)




3. Place the requested number of pieces in the container. Press the **COUNT** key.



4. Fill the container to the desired number of pieces.



5. Press the **PRINT** key to generate a tape/label or to transmit the data to the out port.




6. Remove the pieces from the container and press the **CLEAR** key to return the scale to the weight display.

## Entering Numeric Values for ID, APW, COUNT, or tare

The numeric keypad can be used for entering values for the **PART ID**, the **APW** (average piece weight), the **COUNT**, or **tare** weight. Additional ID registers are available by pressing the **MORE** soft key. To enter known values into those registers, follow the procedure below:

1. Press any of the numeric keys. The 5 soft keys change to the following:




2. When you are finished entering the number, press the desired soft key below the display or press the **tare** hard key to enter that value into the scale register.

NOTE: Numeric entry uses the scale's "medium" size font and is limited to 16 characters.


# Entering Alphanumeric Information into the ID Registers Using the Scale Keypad

The alphanumeric keypad can be used for entering information into the various ID registers for printing or database record purposes. There are 10 ID registers numbered 0-9. The first 7 ID registers have been given common field names listed below. To change the name of an ID field, please refer to the **ID NAME** soft key in the Supervisor menu of the "Supervisor and Technical Setups" manual. Please note that the database does all its sorting based on the IDØ field named PART ID.

Upon pressing the **abc** hard key, the 5 soft keys change to the following:



Additional ID registers are available by pressing the MORE key:



To enter alphanumeric information into any of the the ID registers, after typing in your entry, press the soft key for the desired field. The ID registers have a limitation of 23 characters each.

## Alphanumeric Entry (Cellular Telephone Style)

To enter letters into the scale, press the **abc** hard key on the scale keypad. "ABC" should appear on the bottom left above the soft keys. While "ABC" is displayed, the alphanumeric keypad is in the alphabet mode. The first time a key is pressed, it displays the first letter listed above the number. Pressing the key again moves to the second character and once again for the third character. When the desired character is displayed, you can move on to the next character simply by pressing the next key or the right arrow (➡). The right arrow is necessary when two characters that share the same key follow one another. Letters and numbers can be mixed by simply turning on or off the letter entry mode by pressing the **abc** key.

## Counting with Accuracy Enhancement

When counting parts that are not uniform in weight, it is possible to periodically update the average piece weight (APW) and thereby increase the accuracy. Each time the **UPDTAPW** key is pressed, the scale will update the APW as long as the additional weight is less than or equal to the previous sample weight. If the added weight is more than 100% of the previous sample, the APW will not be updated. For example, starting with a sample size of 10 pieces, add 10 more and press the **UPDTAPW** key. The APW will be recalculated based on a 20 piece sample. When adding 11 or more to the original 10 piece sample, the APW will not be updated. To count using this accuracy enhancement feature, follow the procedure below.

1. Place an empty container on the scale and press the **ZERO** or **tare** key.

2. Press the **SAMPLE** key. The scale display will read "ADD 10 Pieces."

(The sample size requirement can be increased by pressing the **LRG SPL** key repeatedly. The factory default sample sizes are: 10, 25, 50 and 100 PIECES. This sequence of programmed sample sizes will repeat itself as the **LRG SPL** key is pressed.)

3. When the desired sample size is reached, place the requested number of pieces in the container.

4. Press the **COUNT** key. Wait for the "OK" symbol, then slowly add pieces until the displayed count is increased by 100% or less.

5. Press the **UPDTAPW** key. The scale automatically calculates a new average piece weight based on the larger number of pieces, and is ready to continue counting.

If "Calculating stable APW" is not displayed on the top line, the additional pieces have exceeded 100% of the previous sample weight and the APW will not be updated. The message "Unable to recalculate APW: Resample" will be displayed and the scale will continue counting using the previously calculated APW.

**CAUTION:** This accuracy enhancement feature is disabled if the average piece weight has been scanned in from a bar code or entered via a computer or from a numeric keypad.

## Reverse Counting or Kitting

Use this feature to count the number of pieces removed from a full container. This is especially helpful when kitting (counting out a certain number of pieces to be packed together). To perform reverse counting or kitting, use the following procedure:

1. Place a container full of pieces you wish to count on the pan.
2. Press the **ZERO** key then press the **SAMPLE** key.
3. The scale display will read "ADD 10 Pieces". (The sample size requirement can be increased by pressing the **LRG SPL** key repeatedly. The predetermined sample sizes are: 10, 25, 50 and 100 pieces. This sequence of predetermined sample sizes will repeat itself as the **LRG SPL** key is pressed.)
4. When you have selected the desired sample size, remove the indicated number of pieces from the container.
5. Press the **COUNT** key.
6. Remove pieces until the display shows the number of pieces you wish to count out or kit.
7. Press the **ZERO** key.
8. Repeat Steps 6 and 7 as many times as needed.

- NOTE:
- a. If the average piece weight is known, you may press the **—** key, enter the average piece weight, and press the **APW** key in place of Steps 2-5.
  - b. If the sample size is not large enough to satisfy the minimum accuracy requirement the display will read "REMOVE nnn MORE". Remove the specified number of pieces (i.e. nnn) from the container, then press the **COUNT** key.
  - c. It is possible that the required sample size is larger than the quantity needed for each kit. For instance, the required sample size is 100 pieces but only 50 pieces are to be kitted together. In this case, follow steps 1 through 5 above, place the 100 piece sample back into the container and press the **ZERO** key. Continue with steps 6 through 8 above.

## Operating Your Scale Using a QWERTY Keyboard

The back of the removable controller has a port for a standard PS/2® style computer keyboard. To remove the controller from the base, please refer to Section 1, Setting Up Your Scale. Once a QWERTY keyboard is attached to the controller, all scale operations can be performed from the keyboard or in combination with the scale's controller.

### Using the Function Keys F1 - F5

The function keys **F1 - F5** correspond to the soft key functions shown on the bottom of the display. That is, **F1** corresponds to the soft key furthest on the left. **F2** corresponds to the second soft key and so on. When the scale is in the default mode, the **F1** key can be used to ZERO the scale, the **F2** key will recall the SAMPLE size, the **F3** key will initiate a COUNT, the **F4** key will PRINT, the **F5** key will CLEAR and return to weight.

Example functions in the default menu:

**F1** = ZERO  
**F2** = SAMPLE  
**F3** = COUNT  
**F4** = PRINT  
**F5** = CLEAR

### Using the Function Keys F8 - F12

The **F8 - F12** function keys have been reserved for the following hard key functions. **F8** is equivalent to the **tare** key. **F9** will bring up the **menu**. **F10** will switch to a **remote** base (or bring up the base selection menu if multiple bases are attached). **F11** will bring up the ID entry soft keys (**abc** key) and **F12** will cause the scale to do a complete **reset** of all volatile scale registers.



Hard key  
function:

**F8** = TARE  
**F9** = MENU  
**F10** = REMOTE  
**F11** = ABC  
**F12** = RESET

### Entering Numeric Information

The number keys 1 - 9 function the same way as they do on the scale's numeric keypad. Once a number is pressed, the soft keys change to the following:

Numeric  
soft key  
labels:




PS/2® is a registered trademark of IBM.

To enter a value into one of the above registers , use the function key **F1 - F3** that corresponds to the desired soft key (ex: **F2** for entering an APW value). Use the **F9** key to enter a tare value. Use the **F5** Key to EXIT.

### Entering Alphanumeric ID Information

Once a letter is pressed, the scale's display changes to the ID entry mode. At this point, there are two ways of entering the information into the ID register. The function keys **F1 - F4** are available to select registers and move throughout the menu. Another method is to press the ALT key followed by a number between 0 and 9, depending upon the register to be accessed.



#### Alphanumeric ID entry using **ALT** key:

- ALT + 1 = OPRTR
- ALT + 2 = ORDER #
- ALT + 3 = LOT #
- ALT + 4 = DESC
- ALT + 5 = VENDOR
- ALT + 6 = REV #
- ALT + 7 = ID7
- ALT + 8 = ID8
- ALT + 9 = ID9
- ALT + 0 = PART ID


#### Alphanumeric using function key:

- F1= PART ID
- F2= LOT #
- F3= DESC
- F4= MORE
- F1= OPRTR
- F2= ORDER #
- F3= VENDOR
- F4= MORE
- F1= REV#
- F2= ID7
- F3= ID8
- F4= ID9
- F5= EXIT

## Adjusting the Backlighting Option

Super II controllers which are equipped with optional display backlighting are also equipped with controls to vary the brightness of the backlighting. An additional feature of the backlighting control is the automatic battery detector which differentiates between power delivered from an AC adapter and that from an internal or external battery. The power source will determine the maximum level of backlighting available to the display to control power consumption if the battery power saving features have been set through the Technical Menu.

To adjust the backlight brightness, press and hold the **abc** key and simultaneously press the **←** left arrow key repeatedly to reduce brightness or the **→** right arrow key repeatedly to increase brightness to the desired level.





# Soft Key:

# SAVE


## Saving Information to the Database or Transaction Log

Your scale comes equipped with a database for storage of APW's (average piece weights), Tare Weights, Counts, Set Points or complete Transactions with various ID fields and a Time/Date stamp. In order to set up your database for the fields you want to use, please refer to the **DATABASE SETUP** soft key in the "Supervisor and Technical Setups" manual.

The database is sorted based on the IDØ/Part ID field which must be associated with any record going into the database. To view the information in the database, please refer to the **DATABASE** soft key section in the following pages.


Once your scale has gathered all of the information you want to store in the database, you may save that record by following the steps below:

1. Press the **menu** hard key on the controller. The soft keys will change to:



2. Press the **SAVE** soft key.
3. a. Saving to the Database

If the PART ID already has a record associated with it in the database, the following screen will appear:



The PART ID can be overwritten or changed by entering the desired letter (**abc** key) or number followed by the **ACCEPT** soft key.

If the PART ID is correct, press **ACCEPT** to move on to the field saving screen in section b if using a database format that keeps track of the count.

When the **ACCEPT** key is pressed for an existing record where the count is being saved, the following soft keys appear (see "Supervisor and Technical Setups" manual for DATABASE SETUP options).

ADD CT



ADD CT will add the displayed Count to the Count register in the database.

SUB CT



SUB CT will subtract the displayed Count from the Count register in the database.

UPD A/T



UPD A/T will update the APW and/or Tare weight in the database.

UPD ALL



UPD ALL will update all available fields in the database.

**NOTE:** A record cannot be saved to the Database without an identification number (PART ID ) for that record.


You can set up database security features that will prevent the changing, deleting, or addition of records to the database. Please refer to the **SECURITY** soft key in the "Supervisor and Technical Setups" manual.

If you already know the information to be stored in the database, and do not need the scale to develop the needed information (such as an APW), you can enter the record through the **DATABASE** soft key functions described on the following pages.

b. Saving to the Transaction Log

When saving to the Transaction Log, the following screen will appear:

Press SAVE to record the following:		
PART ID: ABC-123		
COUNT:1000	ON:12:00	1/01/00
SAVE		GO BACK



Press **SAVE** to confirm the recording of the listed transaction:

**NOTE:** The fields displayed for Transaction Log recording are selectable in the TRANSAC/SETUP menu in the "Supervisor and Technical Setups" manual.

Transactions for non-scale counted parts can be recorded by manually entering the count in the Transaction Log Saving Screen listed above.

If both the Database and the Transaction Log are turned on, the program will prompt you to choose between the two before displaying the appropriate Saving screen.


## Soft Key: **ACCUM**

### Accumulating Results by Weight or Count

Various displayed weights or counts can be accumulated by using the **ACCUM** soft key in the User's Menu. The **CLEAR** and **COUNT** keys in the Default User Menu can be used to toggle between the weight and the count.

To accumulate results, follow the procedure below:

1. Once the desired weight or count is displayed, press the **menu** hard key on the controller. The soft keys will then change to:



2. Press the **ACCUM** soft key and the scale will then load the Weight or Count into the "ACCUM WT:" or "ACCUM CT:" register and display it on the top line.
3. To continue accumulating the weights for the same part from the same batch, simply put on your new load and press the **menu** hard key and the **ACCUM** soft key again as described in steps 1 and 2 above.
4. To clear out or reset the accumulator register, press the RESET hard key on the controller.


NOTE: Counts for different pieces can be individually accumulated in the Database by simply saving each batch. See the **SAVE** soft key in the previous pages and the **DATABASE FORMAT** soft key in the Supervisor Menu of the "Supervisor and Technical Setups" manual to choose the database selection for storing counts.

# Soft Key: DISPLAY


## Displaying and Deleting Scale Registers

At any time during the weighing or counting process, you may recall or display any number of scale registers in order to view the information or delete it. There are seven (7) weight registers and ten (10) ID registers that can have information in them at any time. To view and/or delete any of the scale registers, follow the procedure below:

- At any time during the weighing or counting process, press the **menu** hard key on the controller. The soft keys will change to:




- Press the **DISPLAY** soft key and the following menu appears that looks as follows:



- Press the number key for the desired register (ex: press the number **2** to view the APW).
- The register and its associated value will be displayed.
- You can then delete that value by pressing the **DELETE** soft key.

Note: You cannot delete the gross weight as it is the weight currently on the platform and the net weight will only change by deleting the tare weight.

- If more than one ID register is active when the number 1 is pressed to display the ID, a new menu with all 10 ID registers is displayed:



- Press the numerical key associated with the ID register and display that register (ie. Press 0 to display Part ID or 3 to display Lot #).


Soft Key:

# DATABASE


## Viewing, Recalling, Changing and Deleting Information in the Database

After having set up the format of the database that you would like to use (see **DATABASE SETUP** soft key in the “Supervisor and Technical Setups” manual), the database is available for changes, additions, deletions or viewing any of the records that are stored in the database unless protected (see **SECURITY** soft key in the “Supervisor and Technical Setups” manual). To access the database records, follow the steps below:

1. Press the **menu** hard key on the controller; the soft keys will change to:



2. Press the **DATABASE** soft key; the soft keys then change to:




### NEW

To add a new database record , type in the PART ID using the numeric or alphanumeric keypad (**abc** key) and press the **NEW** softkey. Enter Part ID, press **ACCEPT**. Press the **DOWN** and **UP** keys to select fields and enter data. When complete, press **SAVE**. Press **CLEAR** to clear that field. To quit without saving changes, press **QUIT**.

### LIST

To view records in the database for selection, editing, or deletion, either press the **LIST** soft key to go to the beginning of the database or type any portion of the PART ID using the numeric or alphanumeric keypad (**abc** key), then press **LIST** to go directly to that record.

1. The display will show the next 4 records in numerical/alphabetical order that most closely match the PART ID and show the variable field information for the database format chosen in the DATABASE SETUP selections of the Supervisor Menu. The display and soft keys change to the following:



2.
    - a) To move through the database, use either the **PRIOR/RECORD**(previous) or **NEXT/RECORD** soft keys.
    - b) To view the record information in order to load it into or delete it from the temporary scale registers, press the **SELECT** key.
    - c) To change any information in the record, use the **EDIT** soft key and refer to section below.
- Note: The PART/ID cannot be changed once it is stored in the database.

## DATABASE RECORD SCREEN

Once the PART ID is selected, the full database record screen is displayed with the following options.

ID:				
TARE:				
APW:				
COUNT				
DOWN ↓	UP ↑	ACCEPT	DELETE	GO BACK

▲

▲

▲

▲

▲

**ACCEPT** will load the displayed information into the temporary scale registers.

**DELETE** will delete the record.

NOTE: A different selection of fields are displayed depending on which Database Format was selected in the Supervisor Setups.

To change data, use **DOWN** and **UP** to move cursor to desired field, enter data and when done, press **SAVE** to save changes. As soon as you begin to type in new data, the soft keys change to:

ID:				
TARE:				
APW:				
COUNT:				
DOWN	UP	SAVE	CLEAR	QUIT

▲

▲

▲

▲

▲

Press **CLEAR** to set all fields to 0. Press **QUIT** to exit without making changes.


# Soft Key: SET PTS

## Entering, Changing, and Using Set Points

The scale is capable of displaying a TARGET Weight or Count along with LOW and HIGH limits.


To program Set Points, follow the steps below:

1. Determine the desired weight or count by using the scale's weighing or counting functions. If you know your desired limits you can simply enter them in the menu while the scale is at zero.
2. Press the **menu** hard key on the controller, and then the **MORE** soft key. The soft keys will change to:



NOTE: \*If ALARMS is enabled, this will be the **ALARMS** key. Set Point settings will be available from the ALARMS screen. See **ALARMS** next page.

3. Press the **SET PTS\*** soft key and the soft keys change to the following with the weight or count displayed in the lower right hand corner:




4. Set Points can be programmed by the following means:
  - a) To enter the displayed weight or count into either the **LOW**, **TARGET**, or **HIGH** register, press the soft key for the appropriate position.
  - b) To enter a value different from the one displayed into either the **LOW**, **TARGET**, or **HIGH** register, type in the desired value using the numeric keypad followed by the soft key for the appropriate position.
  - c) You can have the scale automatically calculate the **LOW** and **HIGH** limits as a percent deviation from the displayed weight or count by typing in the allowable percent error using the numeric keypad followed by the **%** soft key.
5. For better viewing of the displayed weight or count along with its **LOW**, **TARGET**, and **HIGH** set points, press the **GO BACK** soft key to return to the default User Menu.
6.
  - a) The displayed Set Points can be changed at any time by following steps 1-4 listed above.
  - b) To delete the Set Points, press the **reset** hard key on the controller.

# Soft Key: ALARMS


## Setting and Using Alarms

The Super II has three alarm outputs which can be used to signal when the measured weight or count is within a pre-programmed range. To access the **ALARMS** soft key, be certain it has been enabled through the **SET PTS** soft key of the Technical setups menu (See "Supervisor and Technical Manual"). Then follow the steps below:


1. Press the **menu** hard key on the controller, and then the **MORE** soft key. The soft keys will change to:



2. Press the **ALARMS** soft key and the soft keys change to the following:



3. Press the **START** soft key to enable the alarm outputs to respond to the weight/count presently on the scale.
4. Press the **STOP** soft key to freeze the alarm outputs in their present state.
5. Press the **RESET** soft key to change the alarm outputs to their zero weight/count state.
6. Press the **SET PTS** soft key to set the alarms and the soft keys change to the following:





7. Enter the weight value on the numeric keypad or by placing pieces to be counted on the weighing pan and press the **LOW**, **TARGET**, or **HIGH** soft key to set the value for each register.
  - a) To enter a value different from the one displayed into the **LOW**, **TARGET**, or **HIGH** register, type in the desired value using the numeric keypad followed by the soft key for the appropriate register.
  - b) You can have the scale automatically calculate the **LOW** and **HIGH** limits as a percent deviation from the displayed target weight or count by typing in the allowable percent error using the numeric keypad followed by the **%** soft key.
8. For better viewing of the displayed weight or count along with its **LOW**, **TARGET**, and **HIGH** set points, press the **EXIT** soft key to return to the default User Menu.


# Soft Key: UNITS

## Changing the Units of Measure


The scale is capable of displaying weight in eight predefined units of measure as well as a user definable unit of measure. To name and program the user definable unit of measure or to lock out any units of measure to prevent misreadings of the display, please refer to the **UNITS ON** soft key in the Supervisor Menu (see “Supervisor and Technical Setups” manual).

To change units of measure, follow the steps below:

1. Press the **menu** hard key followed by the **MORE** soft key. The soft keys change to the following:



2. Press the **UNITS** soft key and the display then changes to the 8 units of measure available.



3. To select any of the units displayed, press the corresponding number key.

### NOTES:

- a. If any units of measure have been disabled, they will appear with a dark background and will not be available to the user (see **UNITS ON** soft key in the Supervisor Menu of the “Supervisor and Technical Setups” manual to enable or disable any units of measurement).
- b. The last unit of measure, **GRAINS**, is a user definable unit of measure and may be named differently along with a different conversion factor (see **UNITS ON** soft key in the Supervisor Menu in the “Supervisor and Technical Setups” manual for naming and programming the user definable unit of measure).


# Soft Key: COUNTER

## Setting a Print Counter for Box Counting or Serial Number Generation


The scale has the capability of keeping track of a counter each time the **PRINT** key is used. This counter can be used to generate sequential numbers for box or package labeling during kitting operations or to generate a sequential serial number for a label.

To enter the beginning and ending values of a printing sequence, follow the steps below:

1. Press the **menu** hard key, followed by the **MORE** soft key. The soft keys change to the following:



2. Press the **COUNTER** soft key and the soft keys change to the following:



3. To enter values for the **X** unit and **Y** unit (X being the beginning number in the sequence and Y being the ending number), type in the desired number using the numeric keypad followed by the appropriate soft key for the X or Y position. The X and Y counters are limited to 10 numeric characters each.
4. To return to the default User Menu, press the **EXIT** soft key.
5. The X and Y values will remain in memory until X equals Y at which time they will reset to 0. The counter can also be deactivated by entering 0 for the X and Y values following steps 1 - 3 above.

### NOTES:

- a. You do not need to enter a value for X if 1 is the first value in your sequence.
- b. Y must be greater than X.
- c. You may not enter negative numbers.

# Glossary of Terms

<b>Accuracy</b>	The degree of conformity of a measured value to the true value.
<b>APW</b>	Average Piece Weight: the value calculated by dividing the quantity of parts in the sample into the weight of the sample. This value is stored in the scale and divided into the net weight of the bulk load to provide a total count.
<b>Base</b>	The portion of the scale that contains the load cell and receives the object to be weighed.
<b>Controller</b>	The portion of the scale that includes the keypad, display, battery status, LEDs and ports for communicating with the scale base and peripheral devices.
<b>Gross Weight</b>	The weight of the contents (net weight) combined with the weight of the container (tare weight).
<b>ID</b>	Abbreviation for identifier. An identifier can be a part number, lot number, or item description and can be entered into one of several available fields in the database.
<b>Kitting</b>	The counting procedure that involves repeatedly counting out small quantities of a given part to be packaged with other parts that will be used together in an assembly.
<b>Menu</b>	Refers to the numerous choices presented in the display as labels for the soft keys.
<b>Net Weight</b>	The weight of the contents of a container, not including the weight of the container.
<b>QWERTY</b>	Term used to describe the typical keyboard found on a personal computer or typewriter. QWERTY refers to the top row of letters on the keyboard.
<b>Register</b>	A memory location within the scale where data is stored.
<b>Set Points</b>	Target weight or count values that can be entered into the scale for filling or checking weighing applications. Set points can be used to indicate when a weight or count is within a specified range.
<b>Tare</b>	The weight of an empty container. Also, the process of storing the weight of an empty container and zeroing the scale's display.

## **Appendix B**

# **Setra Systems, Inc. Limited Two-Year Scale Warranty**

Setra Systems, Inc. warrants the scales it manufactures to be free from defects in material and workmanship. Upon return, transportation charges prepaid, to Setra's factory within two (2) years of the date of purchase, Setra will repair or replace, at its option, any scale which it determines to contain defective material or workmanship and will return said scale to purchaser, transportation prepaid, at any point in the United States. Setra shall not be obligated, however, to repair or replace scales which have been repaired by unauthorized parties, abused, improperly installed, altered, or otherwise misused or damaged, even if by accident, in any way. Setra will not be responsible for any dismantling, reassembly or reinstallation charge.

Nothing in this warranty shall be construed as a warranty for merchantability or fitness for any specific use or purpose, and this warranty is in lieu of all other warranties, express or implied. Setra shall not be held liable under the terms of this warranty for any special, indirect, incidental or consequential damages claimed in connection with the scale's performance or availability.

Setra Systems, Inc.  
Weighing Systems Division  
159 Swanson Road  
Boxborough, MA 01719  
978 263-1400

**FCC Warning**

This equipment has been tested and found to comply with the limits for a Class A digital device pursuant to Part 15 of FCC Rules. These limits are designed to provide reasonable protection against harmful interference when this equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case, the user must correct the interference.

**Canadian Department of Communications**

This digital apparatus does not exceed the Class A limits for radio noise emissions from a digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la classe A prescrites dans le règlement sur le brouillage Radioélectrique Edicté par le Ministre des Communications du Canada.

## Symbols

----- 12

## A

ABC 11, 12  
AC ADAPTER 6, 9  
AC adapter 9  
ACCEPT 24  
ACCUM 26  
Accuracy 35  
ADJUSTABLE FOOT 6, 7  
ALARMS 30, 31  
Alphanumeric 18  
Alphanumeric ID Information 22  
Alphanumeric Keys 11  
APW 10, 17, 21, 35

## B

Backlighting 23  
BASE 6, 8, 12, 35  
BASE CONNECTOR 6  
BATTERY 6, 9, 12  
BATTERY DOOR 6  
BI 12

## C

Canadian Department of  
Communications 37  
charging 12  
CLEAR 10, 16, 26  
Controller 8, 12, 35  
COUNT 10, 17, 26  
count 16, 19, 21  
Counter 34  
Counting 10, 14, 16  
Counting ,Default 16

## D

Database 28  
database 4  
DATABASE 24  
DATABASE FORMAT 26  
DATABASE SETUP 24, 26  
DC POWER 6  
DELETE 27  
DISPLAY 6, 27  
Display 9  
display 4, 10

## E

EXIT 9, 10

## F

F1 - F5 21  
F8 - F12 21  
FCC 37  
Function Keys 21

## G

GRAINS 33  
Gross Weight 35

## H

HIGH 30, 32

## I

ID 17, 35  
ID NAME 18  
ID Registers 18  
IN 12

## K

KEYBOARD 12  
KEYPAD 6, 18  
Kitting 21, 35

## L

label 10  
LED 12  
LEVEL 6, 7  
LEVELING 7  
LIST 28  
LOAD CELL 6  
LOW 30, 32  
LRG SPL 10, 19, 21

## M

Menu 11, 35

## N

Net Weight 35  
NEXT/RECORD 29  
Numeric Information 21  
Numeric Values 17

## O

OK 12

ON/OFF SWITCH 6  
OUT 12

## P

PAN 6  
PART ID 28  
PRINT 4, 10, 16  
printer 12  
PRIOR/RECORD 29

## Q

QWERTY 12, 21, 35

## R

Register 27, 35  
REMOTE 6, 11  
REMOTE SCALE 6  
reset 9, 11  
Reverse Counting 21

## S

SAMPLE 10  
sample 16, 19, 21  
sample size 10  
SAVE 24  
Scale Registers 27  
Set Points 30, 35  
SET PTS 30, 31  
Soft Keys 16

## T

Tare 11, 14, 35  
TARGET 30, 32

## U

UL 12  
UNITS ON 33  
UPDTAPW 10  
updtapw 19

## W

warranty 36  
WEIGHING 6, 14  
Weighing/Counting 14  
WEIGHINGPLATFORM 6

## Z

ZERO 10, 14, 19, 21  
zero 16

